


---

# Holman

---

## Assembly Guide 40640

---



---

Holman  
Rancho Cordova, CA 95742  
800-343-7486  
InstallationSupport@Holman.com

---

**\*PLEASE READ ALL INSTRUCTIONS AND WARNINGS PRIOR TO ASSEMBLING, INSTALLING, AND USING THIS PRODUCT\***

## Warning



Always check for wires, fuel tanks and lines, brake lines and other important vehicle functionality items prior to drilling and installing all products.

## Tools Needed

3/8" Wrench and Socket

7/16" Wrench and Socket

## Table of Contents

Parts .....	2
Hardware .....	2
Step 1 – Bolt Together .....	3


## Before You Begin

- Read all instructions before installing any Holman product.




## Parts

ITEM NO.	ITEM	PART NUMBER	DESCRIPTION	QTY
1		40640-10	STANDARD PARTITION DS-ASM	1

## Parts (Continued)


ITEM NO.	ITEM	PART NUMBER	DESCRIPTION	QTY
2		40640-20	STANDARD PARTITION PS-ASM	1
3		18-40640	STANDARD PARTITION-HARDWARE	1

## Hardware


ITEM	HARDWARE TO SCALE	PART NUMBER	DESCRIPTION	QTY.
1		11106180	1/4\"-20 X 5/8\" FLANGED HEX HEAD	4
2			1/4-20 FLANGED NYLON INSERT NUT	4
3		11541082	1/4\" FLAT WASHER	8

## Step 1 – Bolt Together


- Place both partition pieces flat on the ground or on a table as shown. Be sure to have the flanges facing upward so you can access the bolt holes.



- Bolt together using a 1/4" x 5/8" flanged hex bolt and a 1/4" flanged lock nut.
- If installing the Center Panel Latch & Door Lock Kit (40620), be sure to bolt two flat washers in between the two panels at each location. This is used to get correct spacing.
- If no door kit is being used, the washers between panels are not needed.



- Repeat 3 more times in the locations as shown below. Be sure to insert the washers between the panels if the door kit is being installed.
- Some like to leave bolts snug tight to allow movement until partition is installed into vehicle.



Follow instructions of desired wing kit to install into vehicle.